



CARTER BILLIARD TABLE INSTALLATION INSTRUCTIONS

Tools required by the installer:

3/8" Drive ratchet and Extension
1/2" & 9/16" Sockets for above
1/2" & 9/16" Combo end wrench
2 and # 3 Phillips screwdriver
Electric drill/ driver
1/8" & 3/16" Drill bits
Speed Square

Prior to installation of the table please check for damaged or missing parts. Call Presidential Billiards at 866-728-2253 if there is a problem. The assembly hardware is packed according to the steps below to facilitate the cabinet assembly.

STEP 1 ASSEMBLE THE CABINET

- 1.1 Lay the cabinet panels upside down on a clean, flat, level surface.
- 1.2 Attach Leg braces to cabinet using bolt and washer from hardware pack.
- 1.3 Loosely assemble the legs to cabinet panels.
- 1.4 Place lower board in dowel holes while attaching legs.
- 1.5 Do not tighten at this time. **Very Carefully** Turn table over.

STEP 2 ATTACH BEAMS

- 2.1 Attach beam bracket to cabinet using bolt from hardware pack
- 2.2 Place beams in beam brackets.
- 2.3 Use bolts, square washers, round washers and nuts from hardware pack, loosely fasten beams to beam brackets.
- 2.4 Using a square, pull the beam flush with the top of the cabinet while making sure the bottom of the beam is resting fully on the brace.
- 2.5 Tighten beam to the bracket. (Note: Long beam must be flush or slightly below short cross beams or slate will not set level on table.)
- 2.6 Starting in one corner tighten bolts connecting cabinet to leg. (Use a square to make sure the panels are flush with the top of the leg.)
- 2.7 Attach Slate blocks to long panels using bolt and washer from hardware pack.

STEP 3 LEVELING THE TABLE & INSTALLING THE SLATE

- 3.1 Place the cabinet in the desired location in the room.
- 3.2 Level the cabinet to the floor, shimming under the legs.
- 3.3 Set the 3 slate pieces in place and pre drill the slate screw holes into the wings with a 3/16" drill bit. Level the table and slate combination with a spirit level both lengthwise and cross wise, shimming as necessary.
- 3.4 Fasten the slate to the wings using the screws provided.
- 3.5 Fill the joints and install the bed cloth.

STEP 4 ASSEMBLING THE CUSHION RAILS & POCKETS

- 4.1 Remove the packaging from the cushion rails and apply the billiard fabric to the cushion rails.
Note: This step may have been completed before the table was delivered.
- 4.2 Lay out all the rails upside down and install the pockets using the bolts supplied. Keep the rail/pocket joint as tight as possible.
WARNING: Use of non-Presidential Billiards pocket bolts will result in damaged rails.
- 4.3 Having bolted the U frame rails together turn the rail and pocket assembly right side up and place on the table.
Caution: Be very careful at this point to avoid cracking a rail.

STEP 5 INSTALLING THE CUSHION RAIL / POCKET ASSEMBLY

- 5.1 Align the rail/pocket assembly and loosely bolt it to the slate surface using the bolts and dome washers provided.
- 5.2 Align the rail/pocket assembly to the slate and tighten the bolts by hand. **(No power tools please!)**
WARNING: Do not over tighten!

Should there be any problems please contact us at:

Presidential Billiards, L.P.

20221 Caroline Way
New Caney, TX 77357

Tel: 281-572-4522

Fax: 281-572-4922

Revised: 03/02/2017

Carter Billiard Table Hardware

STEP 1

1.2	16	5/16" Flat Washers	NE3526
	16	5/16" – 18 x 2" bolts	NU4915
1.3	16	5/16" – 18 x 2" bolts	NU4915
	16	5/16" Flat Washers	NE3526

STEP 2

2.1	12	5/16" – 18 x 3/4" Flange Bolts	NU3960
	4	Beam Brackets "L" shape	NE90702
2.3	4	5/16" - 18 x 3 1/2" bolts	NU00961
	4	5/16" Flat Washers	NE3526
	4	5/16" Dome Tooth Washers	NE3648
	4	5/16" - 18 hex nuts	NU0012
2.7	16	5/16" – 18 x 2" Bolts	NU4915
	16	5/16" Flat Washers	NE3526

STEP 3

3.4	17	# 14 x 2 1/2" Slate screws	NU3940
-----	----	----------------------------	--------

STEP 4

4.2	12	5/16" – 18 x 3/4" Phillips head bolts	NU3971
-----	----	---------------------------------------	--------

STEP 5

5.1	18	5/16" – 18 x 2" bolts	NU4915
	18	3/8" Dome washers	NE3527